



A CSW Industrials Company



INSTALLATION INSTRUCTIONS

TRUAIRE® RETROFIT DIFFUSER Post drywall one piece installation



1 Choose an area of the ceiling free of joist, wires etc. For MV 8" boot, cut a 9 1/4" diameter hole. For MVS 6" boot cut a 7 1/4" diameter hole.



2 Pull flexible duct down through hole in ceiling.



3 6" and 8" stepped collar design tears away to match diameter of flexible duct. (A) Grasp tab to initiate tearing. (B) Pull band around perimeter to release sections.



4 Slide duct over collar and secure tightly using collar tie. (provided)



5 Push both duct and diffuser into the opening until grille contacts the ceiling. Rotate the unit to be parallel with walls in the room.



6 Tighten four screws. Mounting clips automatically rotate to firmly secure the unit to the ceiling.

Manufactured by

RectorSeal, LLC 2601 Spenwick Drive • Houston, TX 77055, USA • 800-231-3345 • rectorseal.com
3255 Wyandotte St East Windsor • ON N8Y 1E9 Canada • 519-966-4901

A CSW Industrials Company. RectorSeal, the logos and other trademarks are property of RectorSeal, LLC, its affiliates or its licensors and are protected by copyright, trademark and other intellectual property laws, and may not be used without permission. RectorSeal reserves the right to change specifications without prior notice. ©2023 RectorSeal. All rights reserved. R50936-0123



RECTORSEAL

A CSW Industrials Company



Manufactured by

RectorSeal, LLC 2601 Spenwick Drive • Houston, TX 77055, USA • 800-231-3345 • rectorseal.com
3255 Wyandotte St East Windsor • ON N8Y 1E9 Canada • 519-966-4901

A CSW Industrials Company. RectorSeal, the logos and other trademarks are property of RectorSeal, LLC, its affiliates or its licensors and are protected by copyright, trademark and other intellectual property laws, and may not be used without permission. RectorSeal reserves the right to change specifications without prior notice. ©2023 RectorSeal. All rights reserved. R50936-0123

INSTRUCTIONS D'INSTALLATION

DIFFUSEUR DE RATTRAPAGE TRUAIRE®

Installation monobloc sur les cloisons sèches



1

Choisissez une zone du plafond exempte de solives, de fils, etc. Pour un soufflet MV de 8", coupez un trou de 9 1/4" de diamètre. Pour le soufflet MVS de 6", coupez un trou de 7 1/4" de diamètre.



2

Tirez le conduit flexible vers le bas à travers le trou du plafond.



3

La conception de collier étagé de 6" et 8" se déchire pour correspondre au diamètre du conduit flexible. (A) Saisissez la languette pour lancer l'action de déchirure. (B) Tirez la bande autour du périmètre pour libérer les sections.



4

Faites glisser le conduit sur le collier et fixez-le fermement à l'aide d'un collier de serrage. (fourni)



5

Poussez le conduit et le diffuseur dans l'ouverture jusqu'à ce que la grille entre en contact avec le plafond. Faites pivoter l'appareil pour qu'il soit parallèle aux murs de la pièce.



6

Serrez les quatre vis. Les clips de montage tournent automatiquement pour fixer solidement l'unité au plafond.

3YR
LIMITED
WARRANTY